

#### S-4611 SDI to DVI converter

Ver:V1.0V02

# **USER MANUAL**

SWIT Electronics Co.,LTD.


Tel:+86-25-85805753 Fax:+86-25-85805296 http://www.swit.cc E-mail: contact@swit.cc

Congratulations on your purchase of this product. Please read this user manual carefully.

#### **Characteristics**

- ◆ Portable 3G/HD/SD-SDI to DVI converter
- ◆ 1 SDI input, 1 SDI loop through output, 1 DVI output
- ◆ SDI embedded audio ch-1 & ch-2 output via 3.5mm socket
- ◆ Heavy duty aluminium housing and bottom screw threads for installation

### **Product View**




- (1) DC 12V: 5.5mm pole DC input
- (2) LED status indicator

Power (red): light up when power is connected

Status (green): light up when DVI port connected and output signal is recognized

SDI Locked (Yellow): light up when SDI input signal is recognized

- (3) 3G/HD/SD SDI LOOP: SDI loop through output (BNC)
- (4) 3G/HD/SD SDI IN: SDI input (BNC)
- (5) DVI OUT: DVI output (DVI-D, 18+1)
- (6) AUDIO OUT: Analog audio output (3.5mm)



Match the screw holes 1&2 with the threads 1&2 of S-4611, and fix the installation plate to the S-4611 by the supplied screws. The screw holes 3, 4, 5, 6 are used to install S-4611 to wall or racks.

## **Specifications**

Input	3G/HD/SD-SDI×1		
Output	3G/HD/SD-SDI×1, DVI×1, Analog audio (3.5mm)×1		
Video Format	DVI	480i / 576i / 720p (60 / 59.94 / 50) / 1080i (60 / 59.94 / 50) /	
		1080p (60 / 59.94 / 50 / 30 / 29.97 / 25 / 24 / 23.98)	
	SDI	SMPTE-425M	1080p (60 / 59.94 / 50)
		SMPTE-274M	1080p (30 / 29.97 / 25 / 24 / 23.98)
			1080i (60 / 59.94 / 50)
		SMPTE-RP211	1080psf (30 / 29.97 / 25 / 24 / 23.98)
		SMPTE-296M	720p (60 / 59.94 / 50)
		ITU-R BT.656	576i (50)
		SMPTE-125M	480i (59.94)
Audio Format	48KHz sync		
Power	≤3W		
Working Voltage	DC 6-18V		
Working Environment	Temperature: $0 \sim +70$ °C, Humidity: $10\%$ - $90\%$		
Dimension	98.5×84.2×29 mm		
Net weight	209g		

### **Maintenance**

- 1. Please do not disassemble the product by yourself.
- 2. Keep the product away from rain or moisture.
- 3. Please use the provided power adapter and if you use third party power adapter, please make sure the voltage range, supplied power, and polarity of power lead are fit.